



Family	Model	Lift Weight kg	FTG mm	Lift Capacity kg	Volts V	Clear Inside Platform Width mm	Clear Inside Platform Length mm	Overall Loader Height mm	Overall Extension of Arc, from stowed position to Maximum Height mm	Overall Loader Width mm	Overall Dimension of outside lift arms Width mm	Overall Loader Depth mm	Overall Loader Depth when on lift title latches @ 795mm mm	Base Plate length mm	Base Plate Width mm	Kick-out is measured from front of base plate edge to the closest point, for the platform has been lowered down 100mm from floor level mm	Kick-out is measured from the front of base plate edge, to the Rotating Pivot side arm or saddle, at floor level mm	Kick-out is measured from, front of base plate edge to Rotating Pivot side arm or saddle at 100mm down mm
E-Series	EDEC08F74130ML	133	800	400kg	12V	740 (715)	1300	1100	0	1100	965	450	462	1000	326	362	410	415

All measurements are to be used as a guide as slight variations may occur between all units

Quick Facts

- Two piece folding expanded mesh platform
- 400kg lifting capacity
- Illuminated platform
- Easy access integrated manual back-up pump and handle
- Durable hand-held control unit
- Dual handles to assist with standee and wheelchair users
- Lift-Tite system automatically secures the platform when in transit
- Durable ripple black finish
- Side or rear door application
- Electrohydraulic power up/gravity down operation
- Mechanically operated out-board barrier
- Equipped with adjustable anti-rattle features to suppress noise during transit
- Modular pump
- Safety yellow automatic mechanical in-board